SYNTHESIS GAS

INTRODUCTION TO PETROCHEMICAL INDUSTRIES

SYNTHESIS GAS

- Synthesis Gas also called SYNGAS, is a fuel mixture consisting primarily of hydrogen, carbon monoxide, and very often carbon dioxide.
- The chemical composition of syngas varies based on the raw materials, processes and the end use.
- Synthesis gas comes from its use as intermediates in creating Synthetic Natural Gas (SNG) and for producing ammonia and methanol.


PRODUCTION OF SYNTHESIS GASES

- Synthesis gas can be produced from many sources, including natural gas, coal, biomass or virtually any hydrocarbon feedstock, by
- 1. Reaction with steam (Steam Reforming)
- 2. Carbon dioxide (Dry Reforming)
- 3. Oxygen (Partial Oxidation)
- 4. Gasification of coal

STEAM REFORMING

- This is the predominant method used in synthesis gases production.
- It means, the reaction of natural gas, hydrocarbon feedstock, coal or biomass with steam, in simple terms.
- Steam reforming of natural gas is sometimes referred to as Steam Methane Reforming (SMR).
- Steam reforming is an endothermic reaction with 206kJ/mol methane needed for conversion.

FLOW CHART OF STEAM REFORMING OF NATURAL GAS



➤ At high temperatures (700°C - 1100°C) and in the presence of a metal based catalyst (nickel), steam reacts with methane to yield carbon monoxide and hydrogen, that is

$$CH_4 + H_2O$$
(steam) CO + $3H_2$

Additional hydrogen can be removed by lower temperature gas-shift reaction with the carbon monoxide produced, in the presence of a copper or iron catalyst, that is

$$CO + H_2O$$
(steam) $CO_2 + H_2$


DRY REFORMING

- Carbon dioxide reformation is a method of producing synthesis gases from the reaction of carbon dioxide with hydrocarbons such as methane.
- The dry reforming reaction maybe represented by

$$CO_2 + CH_4 \longrightarrow 2H_2 + CO$$

- The gases CO_2 and CH_4 , greenhouse gases, are consumed and useful chemical building blocks such as hydrogen and carbon monoxide are produced.
- Typical catalysts are noble metals, Ni or Ni alloys. In addition, activated carbon can be used as an alternative catalyst.


FLOW DIAGRAM FOR DRY REFORMING OF NATURAL GAS



PARTIAL OXIDATION

- It is an exothermic chemical reaction which occurs when a substoichiometric fuel-air mixture is partially combusted in a reformer, creating a hydrogen-rich syngas which can then be put to further use.
- Thermal Partial Oxidation (TPOX) reactions are dependent on the air fuel ratio, which proceeds at temperatures of 1200°C and above.
- Catalytic Partial Oxidation (CPOX), the use of a catalyst reduces the required temperature to a range of about 800°C to 900°C.


FLOW DIAGRAM FOR PARTIAL OXIDATION




GASIFICATION OF COAL

- This is simply the process used to convert coal into gas.
- Coal contains predominantly of carbon compound.
- Coal contains both the organic part and inorganic part.
- ➤ Gas produced from coal gasification contains predominantly CO and H2.
- In the gasifier, the feedstock reacts with steam and oxygen at elevated pressure and temperature.

FLOW DIAGRAM FOR GASIFICATION OF COAL



summary



APPLICATIONS OF SYNTHESIS GASES

- 1. Electricity generation
- 2. Use as gas engines
- 3. As an intermediate for other compounds (ammonia and methanol)

THANK YOU!